



Trizact™ Diamond Red and Blue HX discs For preparation of stone floors

Technical data sheet

TD145

Date: August 2011
Supersedes: May 2011
FG. Page 1 / 1

Description:

The Trizact™ Diamond HX discs are premium quality preparation discs made of resin and diamonds on a durable cloth backing. They are used on stone floors to remove scratches and prepare for protection or polishing.

Special Features:

- Can be used on various stone floors : marble, terrazzo, concrete, granite etc.
- 2 colours: Red (more aggressive; bigger particles) and Blue (less aggressive, smaller particles).
- Optimal preparation performance, removing scratches for a better finish.
- Homogeneous performances from the beginning till the end thanks to the unique 3D construction.
- Durable, enable to prepare large surfaces.
- Can be used under swing machines or autoscrubbers.
- Supplied with pads holders.

Where and When to Use:

The Trizact™ Diamond HX discs can be used with swing machines and autoscrubbers, for wet preparation, steps on stone floors.

Directions for Use:

1. Install 4 Trizact™ Diamond HX RED discs under a non-aggressive pad such as 3M Scotch-Brite™ White or Red floor pad, with the attaching pad supplied with the Trizact™ pads, as shown on the picture below. Preferably use 12,8 cm Trizact™ pads with 406 mm holder pad or higher.

Preferably use 7,68 cm Trizact™ pads with 406 holder pad or smaller.



2. Use a neutral detergent or water. Scrub the floor during 6 passes (back and forth is 2 passes). Under a swing machine, try to make circles for a better overlapping.
3. Vacuum then rinse the floor with 3M Easy Clean or 3M Easy Express flat mop system to remove loosen abrasives from the floor.
4. Install 4 Trizact™ Diamond HX BLUE discs under a non-aggressive pad such as 3M Scotch-Brite™ White or Red floor pad, with the attaching pad supplied with the Trizact™ pads.
5. Use a neutral detergent or water. Scrub the floor during 6 passes (back and forth is 2 passes). Under a swing machine, try to make circles for a better overlapping.
6. Vacuum then rinse the floor with 3M Easy Clean or 3M Easy Express flat mop system to remove loosen abrasives from the floor.
7. Now, the floor is very smooth on hand and ready for the next step: further polishing, crystallization or protection.

Maintenance of pad:

1. Remove pads from the holder.
2. Rinse wash under tap water.
3. Let dry.

Note: Do not machine wash.

Product Characteristics:

Colour: White active dotted side and either RED or BLUE backing side.

Thickness: 5 mm

Dimensions: 2 sizes : 12,8 cm (5 inch) and 7,68 cm (3 inch).

The pad is not significantly affected by water, detergents and cleaners normally used for floor maintenance.

Safety:

User is solely responsible for determining whether the Trizact™ Diamond HX discs are suitable for user's flooring and method of application. Some floors may release dust that could be hazardous to the user or bystanders. Eye, Skin and/or respiratory personal protection equipment may be appropriate to reduce the risks associated with exposure to airborne dust.

Origin:

Made in 3M USA.